



Installation instructions for Alpha Q Pro seat posts

Congratulations on your purchase of the Alpha Q Pro seat post. The unique design of the post will provide you with many miles of increased comfort when installed properly. Follow all instructions carefully. Incorrect installation can lead to damage of the post or bike frame possibly resulting in failure and injury. If you are in any doubt, have the installation carried out by a qualified bike mechanic.

Installation instructions:

- 1) Loosen seat tube binder bolt/clamp of the bicycle frame
- 2) Clean the inside of the seat tube with mild detergent or solvent to remove any grease and dirt that may be inside. This will prevent slippage.
- 3) Tighten the seat tube binder bolt/clamp in 1/4 turn increments until the post is gripped firmly
- 4) Loosen the saddle clamp assembly with a 6mm allen key
- 5) Insert saddle rails in the rail groves of the saddle clamp.
- 6) Make fore/aft and tilt adjustments to the saddle to the desired position.
- 7) Secure the saddle in place by tightening the saddle clamp with a torque wrench to 7-10 ft lbs.

Features:

- Multi-layer carbon shaft provides the optimal stiffness and strength and dampens vibration before it reaches the saddle
- Saddle adjustments are made easily with a single 6mm allen key.
- Generous clamp setback of 25mm
- Light weight : 190 g (270mm size) and 220g (350mm size)

Cautions:

- Do not ride with the post extended beyond the minimum insertion mark.
- Inspect the post for scratches or cracks before each ride. These are possible signs of a damaged seat post. Do not use a damaged post.

Consult your dealer or contact Alpha Q through the web site.
www.alphaqbike.com